

User Manual



FOREVER

CLASSIC+UNIVERSAL

FOR WHITE & LIGHT COLORED COTTON





PRINT SETTINGS

• Image Mode: mirrored

• Media Setting: Multi-Purpose Tray, Heavy Paper or similar



TRANSFER PROCESS

- Place the textile on the lower plate.
- Place the transfer paper onto the T-Shirt.
- Press for 10-15 seconds.
- Remove the transfer paper immediately.
 (Never take the T-Shirt off the press before the transfer paper has been peeled off.)
- For a better washability put a sheet of silicone paper onto your design and press again.



SETTINGS HEAT PRESS

	AUTOMATIC HEAT PRESS	MANUAL HEAT PRESS
PRESSURE	5 bar / 70 PSI	maximum
TEMPERATURE	200°C / 392°F	200°C / 392°F
TIME	10-15 seconds	10-15 seconds
FIXING	10 seconds	10 seconds



WASHING

• Up to 60°C (warm wash cycle). Inside out. Do not use fabric softener or liquid detergent.



DRYING

• Do not tumble dry! Hang dry or line dry recommended



IRONING

• When ironing cover the print with baking paper

